



APPLICATION NOTE



Any Bar code scanner with RS232 output can be used. Any converter Rs232 to Wiegand can be used. The system is tested with Newland FM430 Barracuda - fixed mount barcode scanner.

WIRING



SETTINGS IN THE SOFTWARE

Set the reader as normal "Proximity" reader.

Set the Wiegand Type according to the converter's wiegand output.

