


➤ Procedure for firmware update of the EWSi controller

APPLICATION NOTE


A075

Procedure for firmware update of the EWSi controller


1. Open PROS Client, right-click and select "Firmware Update".




2. Click the "Browse" button.



3. A pop-up window opens. Select the firmware file as shown in the picture below (EWS2_v4.18.xhc) and click the "Open" button.




4. Click the “Upload” button and follow the instructions highlighted in red.



5. The message “Firmware update started” will appear in PROS Client.



6. After the firmware update is completed, the following message will appear in PROS Client: “Firmware update success”.



7. To make sure the EWSi has the latest FW version, right-click the controller and select “Check version”. The firmware version will then appear on the screen.

